

Technical support

Please visit SEUIC's official website “www.chinaautoid.net” to download User Manual , SDK , different Apps or software in order to help you better use the device.


2016 SEUIC Technology . All rights reserved.

It is strictly prohibited to copy, transfer, distribute and store any content in the document in any form without the SEUIC's permission. The content in this manual is subject to change without advance notice.

Company address: No.15,Xinghuo Road
Nanjing High-Tech Zone.China
JIANGSU SEUIC TECHNOLOGY CO., LTD
TEL: 0086-400-677-0876
Company official website: www.seuic.com
Products official website: www.chinaautoid.net
Mailbox: AUTOID@seuic.com
Post code: 210061


Seuic

Quick Start Guide



(Picture 1)

(Picture 2)



(Picture 3)

Applicable to CRUISE1 series

Initial Use

When use the device for the first time, quick tips will pop up and guide you on how to use the device.

Power on


Long press the power button until CRUISE1 vibrates.

Power off

Long press the power button then click the Power off option.

Install Micro SD card and Micro SIM card


As shown below, SIM card slot 1 is located on the bottom, SIM card slot 2 is located on the top, please gently push your card into the slot untill you hear a click sound.
(Note: there is one Micro SD card slot ,please insert Micro SD card in this slot only, please do not attempt to insert unfit card type or card case,which could lead to irreversible damages to the product and the card).



(Picture 4: SIM card and SD card installation diagram)

Charging

1. The device could be charged through USB cable.
 2. USB cable: use the USB cable to connect the terminal to an adapter or PC for charging .
- Red indicator means terminal is charging ; green indicator means terminal is fully charged.
3. Note : If it's not used for a long time, please charge the device at least once a month to extend the lifespan of the battery.



(Picture 5: USB cable charging diagram)

Common functions

■ Connect with PC

Connect your device to PC via the USB cable or a single slot charging dock.

■ Barcode scanning

SEUIC's scan tool or customers's scan tool are optional to scan the barcodes. You can use our device built-in barcode scanning application or the customer-developed scanning application to scan barcode;

Frequently Asked Questions:

Problem 1: There is not light coming out in scanning.

Solution 1: First to check whether the scan engine is closed, if so, please turn it on in "Scan Tool"

Problem 2: One scanning session results in two same barcodes.

Solution 2: Please check whether the integrated scan application and the third party scan application are both activated, if yes, please disable the integrated scan application and set it to "Not Automatically on when power on" in the setting of "Scan Tool".

■ WIFI connection

1. Click "settings" in main screen.
2. Turn on the WLAN option in the wireless and network menu .
3. Click WLAN, the device will search and list the available networks. Please select the one that you want , and then click it to connect. If you select a secured network, you will need to input password.

Note: if WLAN and cellular data are both opened, WLAN is preferred. When WLAN is offline, the system will ask whether to use cellular data if it's available.

■ LTE/WCDMA/EVDO/TD-SCDMA/GSM connection

At initial use , after insertion of SIM card , CRUISE1 will automatically select and register network service provider. The cellular data will be turned on by default.

Attention

1. Do not soak USB cable in water.
2. Please close 2D scan engine when you don't use it , please do not keep it open for a long time.
3. Please do not look directly into the light beam of scan engine during scanning in order to avoid eye injury.
4. Please connect the USB cable to the device first, then connect it to the PC via USB port.
5. When replacing SIM card, please restart the device . In case of Micro SD card, restart of the device is not necessary.

Trouble shooting

1. If the device cannot connect to cellular data, please first check if the SIM card is out of service, then please check whether CRUISE1 support the corresponding network.
2. If the device cannot connect to PC, please check whether the USB cable and the CRUISE1 is correctly connected.
3. If the device cannot enter into sleep mode, please check whether CRUISE1 is using cellular network, or whether CRUISE1 is reading or writing data into NAND.